

37

SBE 26plus Deployment/Recovery Checklist

Serial#: 12812	Location: FR7		
Deployment Date: 8/26/15	Deployment Duration: 6 months		
DEPLOYMENT			
Operator: Quisenberry	Programmed Date: 8/26/15		
Prep Instrument (circle):	CLEANED	TAPED	MARK W/ CONTACT INFO
Installed New Batteries:	YES	NO	Voltage:
Installed Dessicant:	YES	NO	
Check & Clean O-Rings:	YES	NO	
Mark w/ "New Batts & Date":	YES	NO	
Clear Memory (SAMPLENUM=0):	YES	NO	
Update PC clock:	GPS	INTERNET SERVER	
Set Date Time (MMDDYY=, HHMMSS=)	GMT	OTHER Time Zone:	
Sample Setup (INTERVAL=, NAVG=; OUTPUTSAL=)	Interval (s): 180	Navg (#):	Output Salinity (Y/N) Yes
Memory Check: 86400 sec / interval =	samples/day (#):	Total samples:	Total < available samples (Y/N):
Save capture file:	format: SBE#_site_YYYYMM_deploy.cap SBE12812_FR7_201508_deploy	Send DS	Send DC
Start logging (STARTLATER):	Start Date:	00:00:00 on	8/29/15
Close Capture File:	YES	NO	
NOTES: ADD 52647 SBE 56 1856			
RECOVERY			
Operator: Quisenberry	Retrieval Date: 3/5/16		
Prep Instrument (circle):	CLEANED	DRY	UN-TAPED
Update PC clock:	GPS	INTERNET SERVER	
Save capture file:	format: SBE#_site_YYYYMM_recovery. SBE12812_FR7_201603_recovery	Send DS	Send DC
Calculate Time Drift:	22:47:51	(inst) - (pc)	22:48:05 = -16sec
Close Capture File:	YES	NO	
Upload Data File:	format: SBE#_sitename_startYYYYMM-endYYYYMM.asc SBE12812_FR7_201508-201603		
Convert ASC File:	YES	NO	Upload then convert SBE's one at a time per PC
Preview Data:	QUICK SCAN	MATLAB PLOT	QUALITY CONTROL
Back Up Data:	PC	External HD	Server:
NOTES: Bad upload			